

Product Use:



Step 1: Place desired food into the pitcher. Note that product works best when some liquid is used.



Step 2: Put the black cap firmly on the pitcher.



Step 3: Turn the blender on by pushing one of the speed buttons. (If higher speeds are desired, shift the switch to high speed and then push the desired speed button.)

Step 4: If more ingredients are desired, remove the plastic center piece from the cap and add ingredients through that hole.

Step 5: Keep the blender on and adjust speed as necessary until the contents reach the desired consistency.

Step 6: Turn the blender off by pushing the "off" button.